



Assembly Instruction


30168-100, 30168-103, 30168-130



AX8




B X24



CX24



DX8




E X54




F X11




GX8




HX4



J X2



K X1




L X1




Assembly Instruction

30168-100, 30168-103, 30168-130

1.




2.



30168-100, 30168-103, 30168-130

CX16




4.

F X11

K X1

L X1





Assembly Instruction

30168-100, 30168-103, 30168-130

5.



GX8



6.

HX4



EX8



Assembly Instruction

30168-100, 30168-103, 30168-130

7. EX16



Assembly Instruction

30168-100, 30168-103, 30168-130

